

# DEFAULT

## Homescreen



## UI Navigation

Zwift Play	Keyboard	Apple TV
A Select	Select	Select
B Back	Esc Back	Back
◀ Navigate Left	◀ Navigate Left	◀ Navigate Left
▲ Navigate Up	▲ Navigate Up	▲ Navigate Up
▶ Navigate Right	▶ Navigate Right	▶ Navigate Right
▼ Navigate Down	▼ Navigate Down	▼ Navigate Down

## TRAIN - Workout & Group Workout



## Workout

Zwift Play	Keyboard	Apple TV
A Select Action	← Select Action	● Select Action
B Back/Show Menu Bn	Esc Back/Show Menu Bn	◀ Back/Show Menu Bn
Y (Hold) Skip Block	◀ Navigate Action Bar	◀ Navigate Action Bar
Z Return a Ride On	▲ Toggle Action Bar	▲ Toggle Action Bar
Z (Hold) Ride On Bomb	▶ Navigate Action Bar	▶ Navigate Action Bar
◀ Navigate Action Bar	◀ (Hold) Make U-Turn	▼ Close Action Bar
▲ Toggle Action Bar	↑ Increase Intensity	
▼ Navigate Action Bar	↓ Decrease Intensity	
▼ (Hold) Make U-Turn	Tab Skip Workout Block	
LS Increase Intensity		
RS Increase Intensity		
ZL (Push Right) Brake		
ZL (Pull Left) Steer Left		
ZR (Push Left) Brake		
ZR (Pull Right) Steer Right		

## EXPLORE - Free Ride



## Free Ride

Zwift Play	Keyboard	Apple TV
A Select Action	← Select Action	● Select Action
B Back/Show Menu Bn	Esc Back/Show Menu Bn	◀ Back/Show Menu Bn
Y Use Power Up	◀ Navigate Action Bar	◀ Navigate Action Bar
Z Return a Ride On	▲ Toggle Action Bar	▲ Toggle Action Bar
Z (Hold) Ride On Bomb	▶ Navigate Action Bar	▶ Navigate Action Bar
◀ Navigate Action Bar	◀ (Hold) Make U-Turn	▼ Close Action Bar
▲ Cycle Mini Map View	↑ Close Action Bar	▼ Close Action Bar
▼ Toggle Action Bar		
▶ N/A		
▼ (Hold) Make U-Turn		
ZL (Push Right) Brake		
ZL (Pull Left) Steer Left		
ZR (Push Left) Brake		
ZR (Pull Right) Steer Right		

## COMPETE - Races & Group Rides



## Events (Races, Group Ride)

Zwift Play	Keyboard	Apple TV
A Select Action	← Select Action	● Select Action
B Back/Show Menu Bn	Esc Back/Show Menu Bn	◀ Back/Show Menu Bn
Y Use Power Up	◀ Navigate Action Bar	◀ Navigate Action Bar
Z Return a Ride On	▲ Toggle Action Bar	▲ Toggle Action Bar
Z (Hold) Ride On Bomb	▶ Navigate Action Bar	▶ Navigate Action Bar
◀ Navigate Action Bar	◀ (Hold) Make U-Turn	▼ Close Action Bar
▲ Cycle Mini Map View	↑ Close Action Bar	▼ Close Action Bar
▼ Toggle Action Bar		
▶ N/A		
▼ Look Back Camera		
ZL (Push Right) Brake		
ZL (Pull Left) Steer Left		
ZR (Push Left) Brake		
ZR (Pull Right) Steer Right		

## Intersection Functions

When action bar is not in use at intersections, the left, right, and up arrows on the directional pad can be used to make a left, right or go straight.

- ◀ Go Left at Intersection
- ▲ Go Straight at Intersection
- ▶ Go Right at Intersection
- ◀ Navigate Action Bar
- ▶ Navigate Action Bar
- ▼ Dismiss Action Bar

## Action Bar Functions

When action bar is in use, the left and right arrows on the D-Pad will be used to navigate between individual actions.

- ◀ Navigate Action Bar
- ▶ Navigate Action Bar
- ▼ Dismiss Action Bar

## Action Bar Functions

When action bar is active, the left and right arrows on the D-Pad will be used to navigate between individual actions.

- ◀ Navigate Action Bar
- ▶ Navigate Action Bar
- ▼ Dismiss Action Bar

If either situation is active, these actions should take precedent D-Pad default inputs.